



2016-2019 Tundra Prodigy P3 Brake Controller

Mounting Plate

Part# TP3PLT

Installation Instructions Please read **FIRST**

1—Mount plate onto existing panel using 4 provided screws and nuts.



2-----Remove the driver side sill plate and kick plate

3--Remove 2 10 mm bolts holding lower dash finish panel and carefully pull off



4---Remove right side upper dash trim plate, unplug switches, the one with the tow haul switch and trac off switch. Remove switches from plate and install into P3 Mounting Plate.

5--Using the 2 screws provided in kit, push your P3 brake controller into front of P3 Mounting Plate and install screws into



original holes in P3 brake controller



6--Install wiring for P3 mount per instructions with P3, Plug in all switches and reinstall all panels. Done!

6---If using on 2015 and newer, Use only steps 1, 3, 4 and 5

If you have any questions, call Earl at 951-858-3418 BEFORE RETURNING